



Smart Chemistry

ZSIVIRA

DYNAMOL LSW CON

<i>Chemical composition</i>	<i>Blend of Fatty Esters and synthetic substrates</i>
<i>Appearance</i>	<i>Pale Beige Viscous Paste</i>
<i>pH - value 1 : 10</i>	<i>5.0 – 7.0</i>
<i>Charge</i>	<i>Anionic</i>
<i>Stability to electrolytes</i>	<i>Stable to acids and salts under usual tannery conditions. Stable in chrome liquors</i>
<i>Shelf life</i>	<i>Up to 1 year at temperatures between 5 and 40° C.</i>
<i>Dilution</i>	<i>Combinations with other fatliquors have to be stirred thoroughly before dilution. dilution method: 1 : 3 with water of 50 - 60° C.</i>

Field of application:

Fatliquor for bouncy, lightfast and odourless leathers.

Properties and Application:

- *DYNAMOL LSW CONC improves the tensile strength of the leather by relaxing the fibres and penetrating into the leather.*
- *Very Good light fastness*
- *Provides Softness with fullness.*
- *Best for light weight leathers.*
- *When added in Pickling after chrome DYNAMOL LSW CON improves the natural fat and chrome distribution.*
- *When given in dyeing it provides even distribution of dyestuffs with brilliant shade.*
- *In soaking it improves strength of the leather.*

The above information on application on leather is given in accordance to the best of our knowledge and our lab applications. As the usage of the product by the consumer is not under our control, we are not liable for any sort of claims or reimbursements. The product is given without any guarantee/warranty in connection to end use.

ZSIVIRA CHEMIE MERK PRIVATE LIMITED

www.zsiviraindia.com info@zsiviraindia.com



ZSIVIRA

DYNAMOL LSW CON

Usage Quantities:

<i>Chrome Tanning</i>	:	<i>1 %</i>
<i>Soaking</i>	:	<i>upto 2%%</i>
<i>Rechroming</i>	:	<i>upto 2%</i>
<i>Fatliquoring</i>	:	<i>upto 6%</i>

Note : The product being combination of various raw materials, there are Chances of variations in colour and viscosity. The property and Application of the product will remain same.

The above information on application on leather is given in accordance to the best of our knowledge and our lab applications. As the usage of the product by the consumer is not under our control, we are not liable for any sort of claims or reimbursements. The product is given without any guarantee/warranty in connection to end use.